

Digital Input Module on MODBUS RS485

Phone: +1 561 779 5660 E-mail: Info@datexel.com - Web Site www.datexel.com

FEATURES

- Field-Bus remote data acquisition
- Modbus Slave device on RS-485
- Modbus RTU/ Modbus ASCII protocol
- 12 digital inputs
- Watch-Dog alarm
- 2000 Vac galvanic isolation on all ways
- High accuracy
- UL / CE mark
- In compliance to EN-50022 DIN rail mounting

12 digital inputs To Modbus RS-485

DAT 3148/12











GENERAL DESCRIPTION

The device DAT 3148/12 is able to acquire up to 12 digital inputs. The data are transmitted with MODBUS RTU/MODBUS ASCII protocol on the RS-485 network
The device guarantees high accuracy and stable measure versus time and temperature.
To ensure the plant safety, two Watch-Dog timer alarms are provided.

The isolation between the parts of circuit removes eventual ground-loop effects, allowing the use of the device even in the heavy environmental conditions.

The DAT 3148/12 is in compliance with the Directive UL 61010-1 for US market and with the Directive CSA C22.2 No 61010-1 for the Canadian market.

The device is housed in a rough self-extinguishing plastic container which, thanks to its thin profile of 17.5mm only, allows a high density mounting on EN-50022 standard DIN rail.

COMMUNICATION PROTOCOLS

The DAT3148/12 is designed to work with the MODBUS RTU/MODBUS ASCII protocol: standard protocol in field-bus; allows to directly interface DAT3000 series devices to the larger part of PLCs and SCADA applications available on the market.

For the protocol instructions, refer to the User Guide of the device.

USER INSTRUCTIONS

Before to install the device, please read the "Installation Instruction" section.

If the module configuration is unknown, with device powered off, connect the INIT terminal to the GND terminal (ground), at the next power on the device will be auto-configured in the default settings (refer to the User Guide of the device).

Connect power supply, serial bus, digital inputs as shown in the "Wiring" section.

The "PWR" LED state depends on the working condition of the device: see the "Light Signalling" section to verify the device working state.

To perform configuration and calibration operations, read the instructions in the User Guide of the device.

To simplify handling or replacing of the device, it is possible to remove the wired terminals even with the device powered.

TECHNICAL SPECIFICATIONS (Typical @ 25 °C and under nominal conditions)

DIGITAL INPUTS		ISOLATION		
Number of Channels Input voltage (bipolar)	12 OFF State : 0÷3 V ON State : 10÷30 V	Inputs – Supply 200 RS-485 – Supply 200	2000 Vac 50 Hz, 1 min. 2000 Vac 50 Hz, 1 min. 2000 Vac 50 Hz, 1 min 1500 Vac 50 Hz, 1 min.	
Input Impedance Sample time	4.7 KOhm 5 ms	ENVIRONMENTAL CONDITIONS Operative Temperature -10°C +60°C		
Data Transmission Baud Rate Max. distance POWER SUPPLY Power supply voltage	38.4 Kbps 1.2 Km – 4000 ft	UL Operative Temperature Storage Temperature Humidity (not condensed) Maximum Altitude Installation Category of installation Pollution Degree -10°C +40°C -40°C +85°C 0 90 % Indoor Indoor Indoor Il		
Reverse polarity protection Current consumption		MECHANICAL SPECIFICA Material IP Code Wiring Tightening Torque Mounting Weight	ATIONS Self-extinguish plastic IP20 wires with diameter 0.8÷2.1 mm² /AWG 14-18 0.5 N m in compliance with DIN rail standard EN-50022 about 150 g.	
		CERTIFICATIONS EMC (for industrial environment) Immunity Emission UL US Standard Canadian Standard CCN Typology Classification File Number	ronments) EN 61000-6-2 EN 61000-6-4 UL 61010-1 CSA C22.2 No 61010-1 NRAQ/NRAQ7 Open Type device Industrial Control Equipment E352854	

INSTALLATION INSTRUCTIONS

The DAT 3148/12 is suitable to be mounted on DIN rail, in vertical position. For a correct working and a long life of the device, read the following indications.


In case of the devices are mounted side by side, please leave about 5mm between in the following situations:

- Temperature in the cabinet higher than 45 $^{\circ}\text{C}$ and high supply voltage ($>\!27\text{Vdc}$).

Avoid to place raceways or other objects which could obstruct the ventilation slits. It is suggested to avoid that devices are mounted above appliances generating heat; their ideal place should be in the lower part of the panel. Avoid to install the devices in a site where vibrations are present.

It is recommended to use shielded cable for connecting signals. The shield must be connected to an earth wire provided for this purpose. Moreover it is suggested to avoid routing conductors near power signal cables.


CABLING





LIGHT SIGNALLING

LED	COLOUR	STATE	DESCRIPTION	
PWR	GREEN	ON	Device powered	
		OFF	Device not powered or wrong RS-485 connection	
		RAPID BLINK	Communication in progress (the blink frequency depends to the Baud-rate)	
		SLOW BLINK	~1 sec Watch-Dog Alarm condition	

WIRING








(*) Note: for UL installation the device must be powered using a power supply unit classified NEC class 2 or SELV

MECHANICAL DIMENSIONS (mm)



ON: short-circuit to GND